



baja designs.
The Scientists of Lighting

**2015-2018 Ford F150, 2017-2018 Raptor
A-Pillar Mount Kit
Instructions (44-7599)**



185 Bosstick Boulevard • San Marcos • CA • 92069

Phone 760-560-2252 • Fax 760-560-0383

info@bajadesigns.com • www.bajadesigns.com



LIMITED LIFETIME WARRANTY

Baja Designs proudly offers a LIFETIME WARRANTY against manufacturer's defect on all the products that we manufacture.

These are comprehensive warranties; other than the exclusions below – you're covered. If your LED or HID bulb burns out, you're covered. Additionally, cutting off our connector or changing your lenses does not automatically void your warranty.

Exclusions:

Installation errors, abuse, misuse or crash damage. You must be the original owner of the product and can supply proof of purchase.

Baja Designs manufactures its own products as well as resells products manufactured by others. Baja Designs makes no express or implied warranties on products not manufactured by Baja Designs including without limitation any warranties or merchantability and fitness for a purpose. We will however, pass on all warranties made by the manufacturer, who has sole responsibility for performing such warranties.

Baja Designs will pay the freight if your product is less than 90 days old, otherwise defective products must be returned to Baja Designs, Inc., freight prepaid. At our option, we will repair or replace items in question and return them at no charge. If the identical product is no longer available, we will replace with a similar product of equal value. Baja Designs Inc. will not be responsible for any indirect or consequential damages in connection with defective merchandise.

Items purchased through a Baja Designs authorized dealer must be returned through the dealer. Only available on LED auxiliary lights and product must be in sellable condition at MSRP. Product that has been damaged in any way after the original purchase date will be excluded from this guarantee.

Indemnification:

Buyer hereby acknowledges off-roading, racing and driving at night are dangerous activities and that the products and/or supplies purchased from Baja Designs are used in an inherently dangerous activity that may endanger life and limb; and in no event shall the seller, or seller's heirs and assigns, be held liable for consequential damages, nor shall seller's liability on any claim for damages arising out of or connected with the sale, delivery, or use of purchased products and/or supplies exceed the purchase price of the products and/or supplies.



baja designs.
The Scientists of Lighting

15-18 Ford F150 A-Pillar kit Instructions

Tools Required

- 10mm Socket wrench
- 12mm wrench
- 7/16" Socket and open-end wrench
- 3/8" Socket and open-end wrench
- Standard screwdriver (flathead)
- Needle-nosed
- 9/16" Socket wrench and open-end wrench

1. To begin, place windshield wipers in the position shown below on the left. Lift small lever near the base of each wiper and pull wiper straight up from the surface of the windshield to release. Set aside for later.



2. Open the hood. With a Standard screwdriver, gently pry up at the circled locations below until the upper cowl releases. **Do not** pull up more than what is necessary to unclip the tabs.





baja designs.
The Scientists of Lighting

3. Before the cowl can be removed, there are six clips total that need to be removed on the driver side and passenger side upper cowling. Carefully lift the front edge of the driver side cowling just enough to see in and locate the plastic clip fasteners. With the needle-nose pliers, squeeze each as shown below to release. Once driver and passenger side cowlings are unclipped, remove the windshield wiper fluid hose from the cowling and set them aside.

Ford cowling clip fastener OEM part#: W708771-S300



4. Find the Rubber pads supplied with the kit. Place them on the brackets as shown below.



5. Remove the two bolts shown below with a 10mm Socket wrench for the bottom left and a 12mm Socket wrench for the bottom right. Once bolts are removed, carefully orient the bracket from the front of the vehicle, through the gap between the hood and the fender, and onto the two bolt locations. Take whatever precautions necessary (i.e. masking tape). Replace bolts and tighten. Use 10mm open-end wrench for bolt in bottom left picture. Repeat for opposite side of the vehicle.





baja designs.
The Scientists of Lighting

6. Place the passenger side cowling first. Make sure windshield wiper fluid hose is placed back into the grooves. Gently press the wiper rubber over the wiper hub first. Carefully watch the plastic clips to make sure they align properly. There should be a distinct click if they are clasped correctly. Make sure the rubber around the perimeter has seated properly inside the upper fender. Now, press the front edge tabs down over the mating bottom cowl clasps. Repeat for the driver side.
7. Replace the windshield wipers.
Note: they need to be angled like the picture from step 1 while installing.
8. See Squadron/S2 instructions to assemble the standard brackets to the lights.
9. Using the 3/8" hardware included with the lights, mount the Squadron/S2 assemblies to the F150 A-Pillar brackets.

Wiring:

1. With the supplied 55" splitter harness in hand, route the shorter lead to the passenger side light and the longer to the driver side light. Connect the corresponding plugs and tie the harness tight against the firewall away from any hot or rotating components.
2. On the passenger side firewall, there are two large harness plugs that pass through. Taped to those harnesses are the upfitter wires. The bundle of wires nearest the engine are to be used. The other wires route power back into the cab for interior auxiliary accessories.
3. With the supplied upfitter harness in hand, find an appropriate chassis ground and fasten the (-) negative eyelet to the chassis. The (+) positive splice connector will need to be attached to the appropriate OEM upfitter switch wire. The color designations for 2017 and 2018 are listed below. Squadron Pros will need a 10A switch, while Squadron Sports are to use a 5A switch.

2017 Colors

Aux 1 - Green/Blue	15A
Aux 2 - Gray/Yellow	15A
Aux 3 - Violet/Orange	10A
Aux 4 - Brown/Blue	10A
Aux 5 - Gray/Orange	5A
Aux 6 - Yellow/Violet	5A

2018 Colors

Aux 1 - Green/White	15A
Aux 2 - Brown/Blue	15A
Aux 3 - Gray/Yellow	10A
Aux 4 - Green/Yellow	10A
Aux 5 - Brown/White	5A
Aux 6 - Green/Orange	5A

Re-torque all the fasteners after 100 miles.

Your install is now complete! Thank you for choosing Baja Designs.