

Installation Instructions

1. Turn off your ignition.
2. If your vehicle has keyless entry, keep the key fob at least 35 feet (10m) away from the vehicle. Wait 5 minutes to allow for the ECU to shut down completely.
3. Locate your accelerator pedal assembly plug connection.
4. Remove the plug on your gas pedal.
5. Plug male and female connectors into their coordinating plugs on the gas pedal.
6. Make sure cables are tucked into place so they do not effect or endanger your driving.
7. Route the Pedal Commander to where you may easily access it.
8. Use the included alcohol wipe to clean the area where you would like to mount the bracket.
9. Apply the Velcro to the bracket to the cleaned area.
10. Put the pedal Commander into the mounted bracket and you have successfully completed the installation process.

For additional assistance you visit us at www.pedalcommander.com